




User Module

HTTP Login Banner

APPLICATION NOTE



Used symbols

 *Danger* – Information regarding user safety or potential damage to the router.

 *Attention* – Problems that may arise in specific situations.

 *Information or notice* – Useful tips or information of special interest.

 *Example* – example of function, command or script.



Advantech Czech s.r.o., Sokolska 71, 562 04 Usti nad Orlici, Czech Republic
Document No. APP-0041-EN, revised on June 18, 2020. Released in the Czech Republic.

Contents

1 Description of user module	1
2 Configuration	2
3 Related Documents	3

List of Figures

1 Information banner	1
2 Web interface	2

1. Description of user module



User module *HTTP Login Banner* is not contained in the standard router firmware. Uploading of this user module is described in the Configuration manual (see [1, 2]).



The user module is v2 and v3 router platforms compatible.

This module allows user to embed information banner ahead of the login form. Using this banner, it is possible to provide any information to user acceding to the router. Banner may serve as a notice describing the device or such as a warning of how to behave when configuring the router.




Figure 1: Information banner

For configuration *HTTP Login Banner* user module is available web interface, which is invoked by pressing the module name on the *User modules* page of the router web interface. The left part of the web interface (ie. menu) contains only the *Return* item, which switches this web interface to the interface of the router.

2. Configuration

The actual configuration of the *HTTP Login Banner* user module configuration is performed via the form on the right of the web interface. The first item in the configuration form – *Enable HTTP Login Banner* – is used to activate this user module. Then it is necessary to insert text which will be displayed in the information banner to the *Banner Text* window. All changes in settings will be applied after pressing the *Apply* button.

The screenshot shows a web-based configuration interface titled "HTTP Login Banner Configuration". At the top left is a checkbox labeled "Enable HTTP Login Banner". Below it is a large text input field labeled "Banner Text". At the bottom left is a "Apply" button.

Figure 2: Web interface



For displaying text correctly, it is not possible to use national characters!

3. Related Documents

- [1] Advantech Czech: **v2 Routers Configuration Manual** (MAN-0021-EN)
- [2] Advantech Czech: **SmartFlex Configuration Manual** (MAN-0023-EN)
- [3] Advantech Czech: **SmartMotion Configuration Manual** (MAN-0024-EN)
- [4] Advantech Czech: **SmartStart Configuration Manual** (MAN-0022-EN)
- [5] Advantech Czech: **ICR-3200 Configuration Manual** (MAN-0042-EN)



Product related documents can be obtained on *Engineering Portal* at www.ep.advantech-bb.cz address.